CRYSTAL

by MEELECTRONICS®

USER MANUAL

CRYSTAL

by MEELECTRONICS®

SPARKLE & DAZZLE

The *Crystal* by MEElectronics is not only a great addition to any **trendsetter's** accessory collection, but also features spectacular high-definition sound. Presented in a **luxurious** jewelry box, the *Crystal* is the **perfect gift** to dazzle a friend or yourself.

BLING RING

Made with genuine **Swarovski Crystals**, the *Crystal* is effortlessly chic and sparkling, embodying the radiance and brilliance of its namesake. The stunning **metal** housing is sleek and modern, offset by the playful crowning of bold, prismatic crystals.

EAR CANDY

Don't be fooled by the miniature size of the *Crystal* - the full-range 7mm drivers deliver sound that is powerful, yet balanced, allowing you to hear the details in your music with **crystal clarity**.

CRYSTAL

WEARING YOUR EARPHONES

Wearing your earphones correctly is key to a comfortable and secure fit. Incorrect wear will result in poor comfort and sound.

Multiple sets of eartips are included to ensure you get the best fit with your earphones. We recommend trying all of the included eartips. If you experience tinny sound or a lack of bass, try different eartips.

The correct eartip for your ear will fit completely inside the ear canal, reduce outside noise, and provide good bass response.

Please visit **www.meelec.com/manual** for full user manual.

MICROPHONE & REMOTE USE

Basic Remote Operation

for iPhone®, iPad®, iPod® and most Android™ devices:

Function	Operation
Answer incoming phone call	Press the remote button
End phone call	Press the remote button
Play media*	Press the remote button
Pause media	Press the remote button
Skip to next track**	Double-press the remote button
Restart the track/previous track**	Triple-press the remote button

*You may need to open the media player application for initial playback to start.
**Not all media players support this functionality.



Additional remote functions are available with many devices. Visit **meelec.com/phone** for complete compatibility and functionality.

CARE AND CLEANING

- Do not remove from ears or unplug by pulling on the cable. Always grasp the metal part of the plug or earpieces.
- If necessary, clean the earphones with a small amount of hydrogen peroxide on a cotton swab. Swab only the outside of the earphone. Eartips can be removed and rinsed under running water or in hydrogen peroxide. Allow earphones and eartips to dry completely before resuming use.

WARNING

Using headphones at high to moderate volumes for extended periods of time will result in permanent hearing damage. Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.

TROUBLESHOOTING

Visit meelec.com/troubleshooting for solutions to common issues.

WARRANTY

MEElectronics earphones purchased from authorized retailers are covered by a 1-year manufacturer warranty. Visit meelec.com/warranty for warranty information.

MEELECTRONICS®

MEElectronics and its logo are registered trademarks of S2E, Inc. All rights reserved.
iPhone®, iPod®, iPad® are a registered trademark of Apple Inc.
Android™ is a registered trademark of Google Inc.

www.meelec.com